

www.inforenviro.com.cn

简单 专业 快执行

ZBH5040SHBBEV



盈峰环境
INFORE ENVIRO

www.inforenviro.com.cn

简单 专业 快执行




 **盈峰环境**
INFORE ENVIRO

01

02




盈峰环境
INFORE ENVIRO

The background of the slide features a close-up of a silver calculator resting on a yellowed, aged piece of paper. The paper is covered in a grid of handwritten numbers, likely representing a financial ledger or spreadsheet. The numbers are in various currencies, including dollars (\$) and pounds (£), and are arranged in columns. The overall aesthetic is that of a vintage or professional financial document.

CHAPTER

01





按下按钮，系统启动，垃圾箱下降，垃圾箱到位，指示灯亮，电机启动。		
急停	上装控制器断电停止当前动作。	3
工作灯	拨至“开”侧，工作灯打开，拨至“关”侧，工作灯关闭。	4
5	垃圾箱降到位	垃圾箱下降到位，该指示灯亮，否则灭。
6	电机故障	电机及电驱出现故障，该指示灯亮，否则灭。
7	遥控	拨至“开”侧，遥控器可使用，尾部操作盒禁用；拨至“关”侧，遥控器禁用，尾部操作盒可使用。



序 号	按钮名称	功能介绍
1	紧急停止	按下该按钮，上装控制器断电，正在进行的所有动作停止；拔起该按钮，控制器可再次动作。
2	压缩循环	点动“压缩循环”按钮，上料装置进行一次压填循环。
3	停止	按下该按钮，当前动作暂停，电控系统不断电。
4	提桶	垃圾箱复位状态，按住“提桶”按钮并保持，上料装置上行。
5	卸桶	垃圾箱复位状态，按住“卸桶”按钮并保持，上料装置下行。
6	垃圾箱上升	上料装置复位状态，按住“上升”按钮并保持，蜂鸣器鸣叫，支腿伸出，垃圾箱上升。
7	垃圾箱下降	上料装置复位状态，按住“下降”按钮并保持，蜂鸣器鸣叫，垃圾箱下降，支腿收回。
8	刮板张开	将旋钮旋向“刮板张开”，刮板顺时针方向转动。
9	刮板刮合	将旋钮旋向“刮板刮合”，刮板逆时针方向转动。
10	滑板前行	将旋钮旋向“滑板前行”，滑板向车头方向运动。
11	滑板后行	将旋钮旋向“滑板后行”，滑板向车尾方向运动。
12	启动	按下该按钮，无线遥控器通电。



1.

2.

3.

4.




1.

2.

3.

4.

The background of the slide features a close-up photograph of a silver calculator resting on a document. The document contains columns of numbers, many of which are preceded by a dollar sign (\$), suggesting a financial or accounting context. The text 'CHAPTER' is overlaid in white, serif font on a dark green horizontal band.

CHAPTER

02

50h

- 1.
- 2.
- 3.
- 4.
- 5.
- 6.

- 
- 1.
 - 2.
 - 3.
 4. 0

- 
- 1.
 - 2.
 - 3.

THANK YOU !

